

Boss Coupling System 152 - 163

Overview	152
Ground joint	153 - 155
Complete couplings with female spud	153
Stems	153
Wing nuts	154
Knurled nut	154
Female spuds	154
Male spuds	155
Double spuds	155
Holedall®	155
Adapters	156
Wing nut caps	156
Washer seal	157 - 158
Complete couplings with female spud	157
Stems	157
Female spuds	157
Male spuds	158
Double spuds	158
Washers	158
Male stems	159 - 160
LP male stems	160
Menders	160
Spud x Hose Shank	160
Clamps	161 - 162
2 Bolt Type, 2 Gripping Fingers	161
4 Bolt Type, 2 Gripping Fingers	161
4 Bolt Type, 4 Gripping Fingers	162
6 Bolt Type, 3 Gripping Fingers	162
6 Bolt Type, 6 Gripping Fingers	162
Ground joint air hammer couplings	163

Boss Low Pressure System (LPS).... 164 - 178

Components overview	164
Frac fittings	165 - 166
Complete Male / Female Assembly	165
Female	165
Male with nut	166
Suction service fittings	166
O-rings	166
Short ferrules	166
Hammer Union	167 - 169
Nuts	167
One-Piece	167
Two-Piece	167
Three-Piece	167
100-Series	168
200-Series	168
206-Series	168
Caps and plugs	169
One-Piece adapters	170 - 171
Flange	170 - 171

Straight	170
Short	170
45° Elbow	170
150# Flange to weld	171
125# Flange x male NPT	171
Port adapter	171
Elbows	171
King Crimp® Style	172 - 173
Large sleeves	172
Heavy Duty	173
Combination nipples	173
Ferrules	173
Butterfly Valves	174
Frac Pump Elbow Adapters	175
Vent-Lock® Safety Cam and Groove Couplings	176 - 178
Type A	176
Type C	176
EZ Boss-Lock Type C	176
Type D	177
Type E	177
Dust caps	177
Dust plugs	177
EZ Boss-Lock Type H dust caps	177
Accessories	178
Handles	178

D