

TTMA Fittings (Cont.)..... 120-125

Dixon® vapor recovery couplers 122-123
 With probe x adapter 122
 With probe x coupler with probe..... 122
 Coupler with probe x hose shank 122
 Coupler x 45° hose shank 123
 Coupler x female NPT 123
 Bayloc® vapor coupler with locking handle 123
 EZ Boss-Lock Vapor Recovery Coupler with Probe..... 123
 Flange gaskets 124
 Flanged sight flow indicators 124-125
 Sight flow indicator repair kits 125
 Flange screen 125

Railroad tank car connections 126-129

Style A 126
 Style F 126
 Style GF..... 126
 Screen 126
 Style T 127
 Dixon® coupler x tank car thread 127
 EZ Boss-Lock x coupler tank car thread 127
 Railroad unloading assemblies 128
 Dixon tank car adapters..... 128
 Cam and groove railroad tank car gaskets..... 129
 Pin lug wrench..... 129

Swivels 130-144

Swivel joint overview 130-131
 Cap seal 132
 Cap seal numbering system 133
 Split flange 134
 Split flange components 135
 Single plane styles 20, 30 136
 Double plane styles 50, 60, 70..... 136-137
 Triple plane styles 80, 10 137
 Loading arm swivels 138
 Loading arm swivel replacement parts 138
 TTMA flange extensions..... 139
 Loading arms..... 140-141
 Base swivels with counterbalance..... 142
 TTMA handle kit 143
 Counterbalance clamps..... 143
 Top loading valves 144
 Top loading diffusers / T-Deflectors..... 144

API 145-150

5500-Series couplers 145
 Reelcraft® static discharge reel..... 146
 Overfill protection rack monitors..... 147
 FT590-Series terminal test equipment 147
 Compatible systems 148
 Rack monitors 148
 Rack cords 148
 Junction boxes 148
 Dixon MannTek break-away coupling 149
 Rack cord assemblies..... 150
 Rack cord parts 150

ADS 151-156

A100 Outalarm® with probe 151
 A210 Spillguard® system 152-153
 Monitors 152
 Probes 153
 Verification monitor 154
 Ground clamp and junction box 154
 Outage gauge 155
 Gauge rods 155
 Cables 155
 Accessories 156